
#### LED-8029M

## **Installations Instruction**



SKU	<u>Description</u>
LED-8029M30-A	24W Post Top LED, 120-277V, 3000K
LED-8029M40-A	24W Post Top LED, 120-277V, 4000K
LED-8029M57-A	24W Post Top LED, 120-277V, 5700K
LED-8029M30C-A	24W Post Top LED, 347V, 3000K





#### Contents:

1 PCS	LED Retrofit lamp
1 PCS	Re-lamping label
1 PCS	Installation instructions

### Read this before you start installation:

- 1. To avoid possible electric shock, power supply must be turned off at fuse box or circuit breaker before installing or servicing.
- 2. Check your local electrical code. This code sets wiring standards for your area and should carefully studied before starting installation. High voltage wiring connecting the fixture must have a temperature rated minimum of 194°F.
- 3. Inspect existing fixture:
  - Fixtures gaskets/seals must be able to prevent water and insects from entering enclosed fixture.
  - Fixture meets minimum size requirements listed at right.
  - Ballast must be bypassed or removed.
- 4. Consider installing surge/lightning protectors where high lightning activity is present or at facilities where over voltages are common.

INSTALLATION REQUIREMENTS		
Input	120-277VAC (USA)	
Voltage	347VAC ("C" Models)	
Frequency	50/60Hz	
Lamp Holder	E39	
	Outdoor Luminaires	
Approved	(Fully enclosed or with cover or	
Fixtures and	lens to prevent entry of water)	
Locations	<u>Indoor Luminaires</u>	
	(Open or Fully Enclosed)	
Minimum Fixture Size	A <u>minimum</u> of 2" spacing between lamp and fixture housing is required to meet heat rating of LED lamp	
Approved Lamp Orientations	Base Down Base Up Horizontal	
Moisture	UL approved for damp	
Rating	environments	

#### IMPORTANT SAFETY INSTRUCTIONS FOR LED RETROFIT CONVERSION:

FOR USE ONLY WITH HID LUMINAIRES IN ACCORDANCE WITH THE INSTRUCTIONS PROVIDED WITH THIS RETROFIT KIT.



MARNING - RISK OF FIRE OR ELECTRICAL SHOCK. LED retrofit kit installation requires knowledge of the existing luminaire's electrical design.



WARNING - RISK OF FIRE OR ELECTRICAL SHOCK. Install this kit only in luminaires that have the features and dimensions shown in the requirements box.



**MARNING** - Do not make or alter any open holes in an enclosure of wiring or electrical components during kit installation.



**MARNING** - To prevent wiring damage or abrasion, do not expose wiring to sharp edges of housing or other sharp surface.



NARNING - Suitable for DAMP LOCATIONS. Not for use with magnetic ballast. SUITABLE FOR USE IN ENCLOSED LUMINAIRES.

THIS DEVICE IS NOT INTENDED FOR USE WITH EMERGENCY EXITS.




#### **LED-8029M**

## **Installations Instruction**



<u>SKU</u>	Description
LED-8029M30-A	24W Post Top LED, 120-277V, 3000K
LED-8029M40-A	24W Post Top LED, 120-277V, 4000K
LED-8029M57-A	24W Post Top LED, 120-277V, 5700K
LED-8029M30C-A	24W Post Top LED, 347V, 3000K
LED-8029M40C-A	24W Post Top LED, 347V, 4000K
LED-8029M57C-A	24W Post Top LED, 347V, 5700K



#### **Electrical System Guidance**

It is highly recommended that a licensed electrical contractor/electrician be used to install the LED retrofit lamp

#### **Installation:**

Step 1: Disconnect Electrical Power to fixture. Step 2: Remove or wire past the HID ballast.

Step 3: Lamp can operate on any voltage from 120V through 277V or 347V

(C models).

Connect the two common wires from the power source directly to the

corresponding leads to the socket.

**NOTE:** The screw of the lamp holder (not the center contact point)

shall be connected to the NEUTRAL wire (white or gray)

Voltage Wiring Breakdown

120V,277V, & 347V One (1) Hot, One (1) Neutral

208V & 240V Two (2) Hots

480V You must add 480V-277V Autotransformer

to convert circuit to 277V

**Step 4:** Thread the retrofit lamp onto the female socket of the existing

luminaire. Do Not over-torque socket, will cause damage to lamp!

Step 5: Apply the silver adhesive label to the inside of the luminaire where it

will be visible during re-lamping.

**Step 6:** Turn on electrical power to the fixture.

# **Wiring Diagram**

