

TOTALTUBE T8 G3

Ballast Compatibility Chart



Item	Manufacturer	Model	Type
1	GE	GE-132MAX-L/ULTRA	INSTANT START BALLAST
2	GE	GE-232MAX-L/ULTRA	INSTANT START BALLAST
3	GE	GE-332MAX-L/ULTRA	INSTANT START BALLAST
4	GE	GE-432MAX-L/ULTRA	INSTANT START BALLAST
5	GE	GE-132MAX-N/ULTRA	INSTANT START BALLAST
6	GE	GE-232MAX-N/ULTRA	INSTANT START BALLAST
7	GE	GE-332MAX-N/ULTRA	INSTANT START BALLAST
8	GE	GE-432MAX-N/ULTRA	INSTANT START BALLAST
9	GE	GE-132MAX-H/ULTRA	INSTANT START BALLAST
10	GE	GE-232MAX-H/ULTRA	INSTANT START BALLAST
11	GE	GE-332MAX-H/ULTRA	INSTANT START BALLAST
12	GE	GE-432MAX-H/ULTRA	INSTANT START BALLAST
13	GE	GE-132MAX-347-L	INSTANT START BALLAST
14	GE	GE-232MAX-347-L	INSTANT START BALLAST
15	GE	GE-332MAX-347-L	INSTANT START BALLAST
16	GE	GE-432MAX-347-L	INSTANT START BALLAST
17	GE	GE-132MAX-347-N	INSTANT START BALLAST
18	GE	GE-232MAX-347-N	INSTANT START BALLAST
19	GE	GE-332MAX-347-N	INSTANT START BALLAST
20	GE	GE-432MAX-347-N	INSTANT START BALLAST
21	GE	GE-132MAX-347-H	INSTANT START BALLAST
22	GE	GE-232MAX-347-H	INSTANT START BALLAST
23	GE	GE-332MAX-347-H	INSTANT START BALLAST
24	GE	GE-432MAX-347-H	INSTANT START BALLAST
25	GE	GE-132MAX-H-42T	INSTANT START BALLAST
26	GE	GE-232MAX-H-42T	INSTANT START BALLAST
27	GE	GE-332MAX-H-42T	INSTANT START BALLAST
28	GE	GE-432MAX-H-42T	INSTANT START BALLAST
29	GE	GE-159MAX-N/ULTRA	INSTANT START BALLAST
30	GE	GE-132MAX-G-N-DIYB	INSTANT START BALLAST
31	GE	GE-232MAX-G-N-DIYB	INSTANT START BALLAST
32	GE	GE-332MAX-G-N-DIYB	INSTANT START BALLAST
33	GE	GE-432MAX-G-N-DIYB	INSTANT START BALLAST
34	GE	GE-132-120RESDIYB	INSTANT START BALLAST
35	GE	GE-232-120RESDIYB	INSTANT START BALLAST
36	GE	GE-332-120RESDIYB	INSTANT START BALLAST
37	GE	GE-432-120RESDIYB	INSTANT START BALLAST
38	GE	GE-132-120RES-DIY	INSTANT START BALLAST
39	GE	GE-232-120RES-DIY	INSTANT START BALLAST
40	GE	GE-332-120RES-DIY	INSTANT START BALLAST
41	GE	GE-432-120RES-DIY	INSTANT START BALLAST
42	GE	GE-232-120RES-B	INSTANT START BALLAST
43	GE	GE-132MV-N-DIY	INSTANT START BALLAST
44	GE	GE-232MV-N-DIY	INSTANT START BALLAST
45	GE	GE-332MV-N-DIY	INSTANT START BALLAST
46	GE	GE-432MV-N-DIY	INSTANT START BALLAST
47	GE	GE-259MV-N-DIY	INSTANT START BALLAST
48	GE	GE-132-MV-N	INSTANT START BALLAST
49	GE	GE-232-MV-N	INSTANT START BALLAST
50	GE	GE-332-MV-N	INSTANT START BALLAST
51	GE	GE-432-MV-N	INSTANT START BALLAST
52	GE	GE-232MAXP-L/ULTRA	INSTANT START BALLAST
53	GE	GE-259MAX-G-N-DIYB	INSTANT START BALLAST
54	GE	GE260IS-MV-N	INSTANT START BALLAST
55	PHILIPS	ICN-1P32-N	INSTANT START BALLAST
56	PHILIPS	ICN-2P32-N	INSTANT START BALLAST
57	PHILIPS	ICN-3P32-N	INSTANT START BALLAST
58	PHILIPS	ICN-4P32-N	INSTANT START BALLAST
59	PHILIPS	REB-1P32-SC	INSTANT START BALLAST
60	PHILIPS	REB-2P32-SC	INSTANT START BALLAST
61	PHILIPS	REB-3P32-SC	INSTANT START BALLAST
62	PHILIPS	REB-4P32-SC	INSTANT START BALLAST
63	PHILIPS	IOPA-1P32-N	INSTANT START BALLAST
64	PHILIPS	IOPA-2P32-N	INSTANT START BALLAST
65	PHILIPS	IOPA-3P32-N	INSTANT START BALLAST
66	PHILIPS	IOPA-4P32-N	INSTANT START BALLAST
67	PHILIPS	IOPA-1P32-LM-N	INSTANT START BALLAST
68	PHILIPS	IOPA-2P32-LM-N	INSTANT START BALLAST
69	PHILIPS	IOPA-3P32-LM-N	INSTANT START BALLAST
70	PHILIPS	IOPA-4P32-LM-N	INSTANT START BALLAST

71	PHILIPS	GOPA-1P32-SC	INSTANT START BALLAST
72	PHILIPS	GOPA-2P32-SC	INSTANT START BALLAST
73	PHILIPS	GOPA-3P32-SC	INSTANT START BALLAST
74	PHILIPS	GOPA-4P32-SC	INSTANT START BALLAST
75	SYLVANIA	QHE1x32T8/UNV ISL-SC	INSTANT START BALLAST
76	SYLVANIA	QHE2x32T8/UNV ISL-SC	INSTANT START BALLAST
77	SYLVANIA	QHE3x32T8/UNV ISL-SC	INSTANT START BALLAST
78	SYLVANIA	QHE4x32T8/UNV ISL-SC	INSTANT START BALLAST
79	SYLVANIA	QHE1x32T8/UNV ISN-SC	INSTANT START BALLAST
80	SYLVANIA	QHE2x32T8/UNV ISN-SC	INSTANT START BALLAST
81	SYLVANIA	QHE3x32T8/UNV ISN-SC	INSTANT START BALLAST
82	SYLVANIA	QHE4x32T8/UNV ISN-SC	INSTANT START BALLAST
83	SYLVANIA	QHE1x32T8/UNV ISH-SC	INSTANT START BALLAST
84	SYLVANIA	QHE2x32T8/UNV ISH-SC	INSTANT START BALLAST
85	SYLVANIA	QHE3x32T8/UNV ISH-SC	INSTANT START BALLAST
86	SYLVANIA	QHE4x32T8/UNV ISH-SC	INSTANT START BALLAST
87	SYLVANIA	QHE1x32T8/UNV ISL-SC-1	INSTANT START BALLAST
88	SYLVANIA	QHE2x32T8/UNV ISL-SC-1	INSTANT START BALLAST
89	SYLVANIA	QHE3x32T8/UNV ISL-SC-1	INSTANT START BALLAST
90	SYLVANIA	QHE4x32T8/UNV ISL-SC-1	INSTANT START BALLAST
91	SYLVANIA	QHE1x32T8/UNV ISN-SC-1	INSTANT START BALLAST
92	SYLVANIA	QHE2x32T8/UNV ISN-SC-1	INSTANT START BALLAST
93	SYLVANIA	QHE3x32T8/UNV ISN-SC-1	INSTANT START BALLAST
94	SYLVANIA	QHE4x32T8/UNV ISN-SC-1	INSTANT START BALLAST
95	SYLVANIA	QHE1x32T8/UNV ISH-SC-1	INSTANT START BALLAST
96	SYLVANIA	QHE2x32T8/UNV ISH-SC-1	INSTANT START BALLAST
97	SYLVANIA	QHE3x32T8/UNV ISH-SC-1	INSTANT START BALLAST
98	SYLVANIA	QHE4x32T8/UNV ISH-SC-1	INSTANT START BALLAST
99	SYLVANIA	QHE1x32T8/347 ISL-SC	INSTANT START BALLAST
100	SYLVANIA	QHE2x32T8/347 ISL-SC	INSTANT START BALLAST
101	SYLVANIA	QHE3x32T8/347 ISL-SC	INSTANT START BALLAST
102	SYLVANIA	QHE4x32T8/347 ISL-SC	INSTANT START BALLAST
103	SYLVANIA	QHE1x32T8/347 ISN-SC	INSTANT START BALLAST
104	SYLVANIA	QHE2x32T8/347 ISN-SC	INSTANT START BALLAST
105	SYLVANIA	QHE3x32T8/347 ISN-SC	INSTANT START BALLAST
106	SYLVANIA	QHE4x32T8/347 ISN-SC	INSTANT START BALLAST
107	SYLVANIA	QHE1x32T8/347 ISH-SC	INSTANT START BALLAST
108	SYLVANIA	QHE2x32T8/347 ISH-SC	INSTANT START BALLAST
109	SYLVANIA	QHE3x32T8/347 ISH-SC	INSTANT START BALLAST
110	SYLVANIA	QHE4x32T8/347 ISH-SC	INSTANT START BALLAST
111	SYLVANIA	QTP1x32T8/UNV ISL-SC	INSTANT START BALLAST
112	SYLVANIA	QTP2x32T8/UNV ISL-SC	INSTANT START BALLAST
113	SYLVANIA	QTP3x32T8/UNV ISL-SC	INSTANT START BALLAST
114	SYLVANIA	QTP4x32T8/UNV ISL-SC	INSTANT START BALLAST
115	SYLVANIA	QTP1x32T8/UNV ISN-SC	INSTANT START BALLAST
116	SYLVANIA	QTP2x32T8/UNV ISN-SC	INSTANT START BALLAST
117	SYLVANIA	QTP3x32T8/UNV ISN-SC	INSTANT START BALLAST
118	SYLVANIA	QTP4x32T8/UNV ISN-SC	INSTANT START BALLAST
119	SYLVANIA	QTP1x32T8/UNV ISH-SC	INSTANT START BALLAST
120	SYLVANIA	QTP2x32T8/UNV ISH-SC	INSTANT START BALLAST
121	SYLVANIA	QTP3x32T8/UNV ISH-SC	INSTANT START BALLAST
122	SYLVANIA	QTP4x32T8/UNV ISH-SC	INSTANT START BALLAST
123	SYLVANIA	QHE1x59T8/UNV ISL-SC	INSTANT START BALLAST
124	SYLVANIA	QHE2x59T8/UNV ISL-SC	INSTANT START BALLAST
125	SYLVANIA	QHE3x59T8/UNV ISL-SC	INSTANT START BALLAST
126	SYLVANIA	QHE4x59T8/UNV ISL-SC	INSTANT START BALLAST
127	SYLVANIA	QHE1x59T8/UNV ISN-SC	INSTANT START BALLAST
128	SYLVANIA	QHE2x59T8/UNV ISN-SC	INSTANT START BALLAST
129	SYLVANIA	QHE3x59T8/UNV ISN-SC	INSTANT START BALLAST
130	SYLVANIA	QHE4x59T8/UNV ISN-SC	INSTANT START BALLAST
131	SYLVANIA	QHE1x59T8/UNV ISH-SC	INSTANT START BALLAST
132	SYLVANIA	QHE2x59T8/UNV ISH-SC	INSTANT START BALLAST
133	SYLVANIA	QHE3x59T8/UNV ISH-SC	INSTANT START BALLAST
134	SYLVANIA	QHE4x59T8/UNV ISH-SC	INSTANT START BALLAST
135	SUNPARK	U-1/32ISE	INSTANT START BALLAST
136	SUNPARK	U-2/32ISE	INSTANT START BALLAST
137	SUNPARK	U-3/32ISE	INSTANT START BALLAST
138	SUNPARK	U-1/32ISE-HBF	INSTANT START BALLAST
139	SUNPARK	U-2/32ISE-HBF	INSTANT START BALLAST
140	SUNPARK	U-1/32ISE-LBF	INSTANT START BALLAST

141	SUNPARK	U-2/32ISE-LBF	INSTANT START BALLAST
142	SUNPARK	U-2/32IS	INSTANT START BALLAST
143	SUNPARK	120-2/32IS-HPF	INSTANT START BALLAST

Note: 1. The tube may not work with some of the listed ballasts due to age, and possible custom specifications.
2. The tube may work with some ballasts that are not covered by the above list, contact us, and ask us to perform a test.
3. It is strongly recommended to do a sample installation before placing an order.