

**LED WORK LIGHT INSTALLATION INSTRUCTIONS**



These instructions apply to the LED-9002-50-5PK work lights.  
 Prior to installation, please read the entire installation instructions.  
 Suitable for use in dry, damp or wet locations.  
 To reduce risk of electric shock and fire, do not connect any equipment or devices to the light string.  
 Do not modify or cut any cables, housings or lamps.  
 Not for use in environments where explosive or corrosive gases are present.

This device is not intended for use with Emergency Exits.



**INSTALLATION REQUIREMENTS**

Model	Input Voltage	Power consumption	Total Length	Total lumen output	Ingress Protection	Lamp Size
LED-9002-50K-5PK	120 VAC 50/60 Hz	100W	50 feet	10,000	IP65 / Wet Location	4.2" diameter x 6.9" height

**CONTENTS**

1 string of 5 work lights
1 Instruction Sheet

**INSTALLATION INSTRUCTIONS**

**INSTALLATION NOTES**

- Lights are delivered in a continuous string of 5 lights. Please do not cut, disassemble or disconnect the lights, housings or wiring.
- Use caution when handling the lights, especially in wet environments. Turn off or disconnect power to lights before handling lights.

- 1.) Ensure that the power supply provides 120VAC, and has adequate capacity for the lights that will be installed. Only use power supply that has GFCI protection.
- 2.) Position the lights where desired. If attaching to an overhead pipe or support, please ensure that it has adequate strength to support the lights. Use a strong cable tie, chain or wire to securely fasten the light to the overhead support.  
 After mounting the lights, please ensure that:
  - Lights are clear of any flammable materials.
  - Lights and cables are clear of anything that may cause damage such as sharp objects, abrasive objects and impact.
  - Lights and cable are clear of personnel or equipment that may cause damage or injury.
  - Do not use in environments where explosive or corrosive gases are present.
- 3.) When all lights are securely mounted, plug in the power cable to confirm that lights are operating correctly.